



# A 2710 USB MP3 Audio Player

## OVERVIEW

The A 2710 is a compact MP3 audio player designed for BGM systems in commercial installations requiring playback from a USB memory stick, or as a simple low cost domestic player interface. The unit simply connects to any standard RCA input and provides typical CD player style functionality ie: play/pause & track skip. Line output level volume is adjustable via the side panel.

## FEATURES

- Support MP3 folder hierarchy structure ie: will browse music inside folders on a memory stick
- Compact size
- Line level volume adjustment
- Simple plug and play operation
- Box flange allows mounting to any surface

## OPERATION

The A 2710 is compatible with USB flash memory sticks and memory cards (such as SD/SDHC/CF etc) when used in conjunction with a card reader.

1. Connect to 12VDC plugpack (not included).
2. Connect RCA lead to player output and to your amplifier input.
3. Set volume level to minimum
4. Press play to commence MP3 playback
5. Adjust volume to desired level.
6. To skip tracks, press the "PREV" or "NEXT" buttons.

## SPECIFICATIONS

Output impedance: .....10K $\Omega$   
Line gain: .....0dB  
S/N ratio: .....>100dB  
Frequency response: .....20Hz - 20kHz ( $\pm$ 1dB)  
Dimensions: .....100L x 40H x 55Wmm  
Weight: .....300gm

**For repair or service please contact your place of purchase. Note: Under no circumstances should you attempt to repair the unit yourself as this will invalidate the warranty! This appliance is not intended for use by young children or infirm persons without supervision. Young children should be supervised to ensure they do not play with the appliance.**

**NOT FIELD SERVICEABLE.**

**Imported & Distributed By:**

Altronic Distributors Pty Ltd. Perth W.A. 6000

**Ph. 1300 780 999 Fax 1300 790 999**

**[www.altronics.com.au](http://www.altronics.com.au)**